

Continue



Dyson ball animal 2 operating manual

Wash filters with cold water every 3 months to ensure optimal performance and longevity of your Dyson appliance. Your Dyson appliance comes with a 5-year guarantee, which covers parts and labor for the specified period. For any inquiries or concerns about your appliance, contact the Dyson Helpline using your serial number and purchase details. Before operating your Dyson appliance, please read all instructions and cautionary markings in this manual and on the appliance itself. Basic precautions should be taken while using electrical appliances, including avoiding blockages that may cause overheating or injury. Regularly wash filters with cold water to maintain performance. Additionally, take note of the following safety guidelines: - Lay the appliance on its back during assembly. - Ensure the cleaner head is securely attached and plugged into the twin-block connection on the body of the appliance. - Check for blockages that may cause overheating or injury. If you encounter any issues, follow the instructions in 'Looking for blockages'. - Do not operate the wand release catch if it becomes blocked. - Switch off and unplug the appliance immediately to avoid personal injury. For further assistance, visit the Dyson website or contact their customer care team. months for maintenance of filters that might need more frequent cleaning if vacuuming fine dust. Upon registering your guarantee, you'll receive coverage for parts and labor for 5 years from purchase date, subject to terms. If you have questions about your Dyson appliance, call the Dyson Helpline with serial number and details. As a registered owner, you can stay updated on new inventions, services, and products before anyone else. You can opt-in to receive updates from us or our partners. Please note that registration is required for the 5-year guarantee. To register by mail, complete the form provided and return it to Dyson. Before using your appliance, read all instructions and cautionary markings in this manual and on the appliance. To reduce the risk of fire, electric shock, or injury: 1. Use by children aged 8+ under adult supervision, or those with reduced capabilities. 2. Do not use as a toy; supervise children near the appliance. 3. Only use as described in this manual; avoid unauthorized maintenance. 4. Suitable for dry locations only; do not use outdoors or on wet surfaces. 5. Handle plugs and appliances with dry hands. 6. Replace damaged cables or plugs to avoid hazards. 7. If the appliance is malfunctioning, has been damaged, or received a sharp blow, contact the Dyson Helpline for assistance. Remember to always follow basic precautions when using electrical appliances. Do not expose your Dyson vacuum cleaner to water, extreme temperatures or physical stress as it may be damaged. Follow these guidelines for maintenance and safe usage. 1. Do not use if exposed to rainwater or dropped, contact the manufacturer. 2. Contact customer support when service or repair is required. 3. Avoid disassembling the appliance as incorrect reassembly can cause electrical shock or fire. 4. Keep cables away from heated surfaces and avoid stretching them. 5. Place cables out of reach of children and pets to prevent tripping hazards. 6. Grasp the plug, not the cable, when unplugging to avoid accidents. 7. Do not use the appliance near open flames or in areas with flammable materials. 8. Keep hair and loose clothing away from moving parts to avoid injury. 9. Regularly clean dust and debris from the filter and bin to ensure proper airflow. Follow these safety guidelines to get the most out of your Dyson vacuum cleaner and ensure safe usage. Dyson Customer Care Information: Monday to Friday: 8am-8pm, Saturday & Sunday: 8am-6pm UK: 0800 298 0298 ROI: 01 475 7109 Register online at www.dyson.co.uk/register or www.dyson.ie/register. DYSON CUSTOMER CARE Thank you for purchasing a Dyson appliance. After registering your 5 year guarantee, your appliance will be covered for parts and labour during this period. Visit www.dyson.co.uk/support (UK) or www.dyson.ie/support (ROI) for online help, support videos, general tips and useful information about Dyson. Please note the serial number on your rating plate for future reference. Contact Us Dyson UK: Website - www.dyson.co.uk/support Dyson Helpline: 0800 298 0298 Email: askdyson@dyson.co.uk Address: Dyson Technology Limited, Tetbury Hill, Malmesbury, Wiltshire, SN16 0RQ Dyson ROI: Website - www.dyson.ie/support Dyson Helpline: 01 475 7109 Email: askdyson@dyson.ie Address: Dyson Ireland Limited, Office 2, Central Park, Leopardstown, Dublin 18, Ireland

Dyson animal ball 2 instructions. Dyson ball animal 2 manual. Dyson ball animal 2 assembly.